



Quickie 2 Configurator Tips:

How to open Caster Wheel and Wheel Lock Categories







1. Front Seat Height selection is required to open “Caster Wheels” category
2. “Seat Depth” and “Frame Depth” selections is required to open “Wheel Lock” category
3. Our old configurator allowed users to choose these options without any selections. In our new configurator, these picks are required to open categories.
4. By clicking the question mark icon  on the right of each category, it will show the reason why these categories are grey out. It will also, provide helpful information to why you have red flags.

(Example for #1)
 Caster Wheel section will open once you have selected a “Front Seat Height” option



TW 6/21/2017

(Example for #2) Wheel lock section will open once you have selected “Seat Depth and Frame depth” option

Seat Depth		
<input type="radio"/> Reset	<input type="radio"/> 15" Seat Depth \$0.00	<input type="radio"/> 18" Seat Depth \$0.00
<input type="radio"/> 12" Seat Depth \$0.00	<input checked="" type="radio"/> 16" Seat Depth \$0.00	<input type="radio"/> 19" Seat Depth \$75.00
<input type="radio"/> 13" Seat Depth \$0.00	<input type="radio"/> 17" Seat Depth \$0.00	<input type="radio"/> 20" Seat Depth \$550.00
<input type="radio"/> 14" Seat Depth \$0.00		
Frame Depth		
<input type="radio"/> Reset	<input type="radio"/> 15" Frame Depth \$0.00	<input type="radio"/> 18" Frame Depth \$0.00
<input type="radio"/> 13" Frame Depth \$0.00	<input checked="" type="radio"/> 16" Frame Depth \$0.00	<input type="radio"/> 19" Frame Depth \$0.00
<input type="radio"/> 14" Frame Depth \$0.00	<input type="radio"/> 17" Frame Depth \$0.00	<input type="radio"/> 20" Frame Depth \$0.00
Wheel Lock (Seat Depth and Frame Depth selections is require to open Wheel Lock category)		
<input checked="" type="radio"/> Reset	 <input type="radio"/> Ergo Scissor \$110.00	 <input type="radio"/> Unilateral Left \$300.00
 <input type="radio"/> High Mount Push \$0.00	 <input type="radio"/> Compact \$125.00	<input type="radio"/> Omit Wheel Lo \$0.00
 <input type="radio"/> High Mount Pull \$0.00	 <input type="radio"/> Unilateral Right \$300.00	

If you need further assistance, please call Customer Service 1-800-333-4000